

05-106 and 05-104

Beeper mR and Beeper III Personal Radiation Monitors

Technical Data



05-106 Beeper mR

The slim, compact Beeper mR is the ideal personal monitoring device for alerting personnel to the presence of x-ray or gamma radiation in medical, industrial or research settings. It accurately measures and displays the accumulated radiation dose received on an easy-to-read LCD display. The only control is a recessed switch for operation (on and off), which ensures that the instrument cannot be turned off accidentally.

Beeper mR is an enhanced version of the highly popular Beeper III and utilizes the same proven technology. The frequency of loud "beeps" increases as a function of the radiation field intensity: from one beep every 15 minutes to 30 minutes in the presence of background radiation, to becoming a continuous sound in high radiation fields. A series of quiet "clicks" indicates the instrument is properly functioning.

05-104 Beeper III

The Beeper III is a simple, convenient instrument for alerting personnel to the presence of x-ray or gamma radiation. The instrument operates continuously and provides a clear, audible indication of dose rates. While it produces a "bleep" every 15 minutes for normal background radiation, the frequency of "beeps" increases with the dose rate until a continuous tone is achieved in high radiation fields.

Key features

05-106 Beeper mR

- Continuously monitors x-ray and gamma radiation exposure and provides instant, accurate readings
- LCD display can be easily read with the instrument in-pocket
- Sturdy casing with pocket clip protects against damage
- Features visible and audible "battery low" indicators
- Energy and polar responses provide reliable readings that match those from TLDs and film badges

05-104 Beeper III

- Provides a continuous indication of gamma or x-ray radiation dose rate
- Lightweight, pocket-size unit that is secured by a clip
- No controls or adjustments are required

Specifications

| 05-106 Bleeper mR | |
|---|--|
| Bleep rates for background radiation | Approx. 1 bleep every 15 minutes to 30 minutes |
| 1 mR/h | Approx. 1 bleep every 20 seconds |
| 100 mR/h and above | Continuous signal to at least 60 Sv/h (6000 R/h) |
| Energy range | 45 keV to 6 MeV (± 25 %) |
| Doserate response | Linear to 5 R/h (± 20 %) |
| Display | LCD 0.1 mR to 999,999.9 mR |
| Battery | Three alkaline batteries, size AAA Typical battery life is one year |
| Temperature range | -20 °C to 50 °C (4 °F to 122 °F) |
| Dimensions (WxD) | 3.56 cm x 15.24 cm (1.4 in x 6 in) |
| Display area | 1.52 cm x 2.29 cm (0.6 in x 0.9 in) |
| Weight | 0.11 kg (0.25 lb) |
| 05-104 Bleeper III | |
| Sensitivity to background radiation | Approx. 1 bleep per 15 minutes |
| 1 mR/hr | Approx. 1 bleep per 20 seconds |
| 100 mR/hr and up | Continuous signal (to at least 6000 R/hr) |
| Energy range | 45 keV/h to 6 MeV |
| Temperature range | -20 °C to 50 °C (-4 °F to 122 °F) |
| Batteries | Two alkaline AAA Battery life approximately one year |
| Construction | Plastic case with clip |
| Dimensions (WxDxH) | 2.54 cm x 13.97 cm x 1.60 cm (1 in x 5.5 in x 0.63 in) |
| Weight | 0.08 kg (0.17 lb) |

About Fluke Biomedical

Fluke Biomedical is the world's leading manufacturer of quality biomedical test and simulation products. In addition, Fluke Biomedical provides the latest medical imaging and oncology quality-assurance solutions for regulatory compliance. Highly credentialed and equipped with a NVLAP Lab Code 200566-6 accredited laboratory, Fluke Biomedical also offers the best in quality and customer service for all your equipment calibration needs.

Today, biomedical personnel must meet the increasing regulatory pressures, higher quality standards, and rapid technological growth, while performing their work faster and more efficiently than ever. Fluke Biomedical provides a diverse range of software and hardware tools to meet today's challenges.

Fluke Biomedical Regulatory Commitment

As a medical test device manufacturer, we recognize and follow certain quality standards and certifications when developing our products. We are ISO 9001 and ISO 13485 medical device certified and our products are:

- NIST Traceable and Calibrated
- UL, CSA, ETL Certified, where required
- NRC Compliant, where required

Ordering information

Model

05-106 Bleeper mR Radiation Monitor
05-106-2200 Bleeper µSv Radiation Monitor
05-104 Bleeper III Personal Radiation Monitor

Fluke Biomedical.

Better products. More choices. One company.

Fluke Biomedical
 6045 Cochran Road
 Cleveland, OH 44139-3303 U.S.A.

Fluke Biomedical Europe
 Science Park Eindhoven 5110
 5692EC Son, The Netherlands

For more information, contact us:

In the U.S.A. (800) 850-4608 or
 Fax (440) 349-2307
 In Europe/M-East/Africa +31 40 267 5435 or
 Fax +31 40 267 5436
 From other countries +1 (440) 248-9300 or
 Fax +1 (440) 349-2307
 Email: sales@flukebiomedical.com
 Web access: www.flukebiomedical.com

©2008-2013 Fluke Biomedical. Specifications subject to change without notice. All OEM company trademarks are implied. Printed in U.S.A. 12/2013 3191574C_EN

Modification of this document is not permitted without written permission from Fluke Corporation.